

Marke	ccm	Bezeichnung	Baujahr
KAWASAKI	400	Z400 F	1984 - >
KAWASAKI	400	Z400 GP	1983 - 1984
KAWASAKI	400	Z400 J	1980 - 1983
KAWASAKI	500	Z500 B	1979 - 1980
KAWASAKI	500	Z500 B	1981 - 1983
KAWASAKI	500	Z500 F Unitrak	1983 - 1984
KAWASAKI	550	KZ 550	1980 - 1983
KAWASAKI	550	KZ 550 B	1981 - 1982
KAWASAKI	550	KZ 550 GP	1981 - 1981
KAWASAKI	550	KZ 550 LTD	1980 - 1982
KAWASAKI	550	KZ GPZ550 Unitrak	1982 - 1983
KAWASAKI	600	GPZ600 R	1985 - 1989
KAWASAKI	600	GPZ600 R	1990 - 1997
KAWASAKI	600	ZZR600	1993 - 2001
KAWASAKI	600	ZZR600	2002 - 2005
KAWASAKI	600	ZZR600	2006 - 2007
KAWASAKI	650	Z650	1977 - 1978
KAWASAKI	650	Z650 Custom	1978 - 1980
KAWASAKI	650	Z650 SR	1979 - 1980
KAWASAKI	750	GPX750R	1987 - 1990
KAWASAKI	750	Z750 Y LTD (Twin)	1981 - 1984
KAWASAKI	750	ZXR750	1989 - 1989
KAWASAKI	750	ZXR750	1990 - 1990
KAWASAKI	750	ZXR750	1991 - 1992
KAWASAKI	750	ZXR750	1993 - 1995
KAWASAKI	750	ZXR750 R	1991 - 1992
KAWASAKI	750	ZXR750 R	1993 - 1995
KAWASAKI	800	VN800	1995 - 1996
KAWASAKI	900	ZX-9R 900	1994 - 1995
KAWASAKI	900	ZX-9R 900	1996 - 1997
KAWASAKI	900	ZX-9R 900	1998 - 1999
KAWASAKI	900	ZX-9R 900	2000 - 2001
SUZUKI	400	GS400	1977 - 1983
SUZUKI	400	GS400 E	1978 - 1983
SUZUKI	400	GSX400 E	1983 - 1984
SUZUKI	400	GSX400 E	1985 - 1987
SUZUKI	400	GSX400 S Sport	1983 - 1984
SUZUKI	400	GSX400 S Sport	1985 - 1987
SUZUKI	425	GS425 N/EN	1979 - 1982
SUZUKI	450	GS450 E	1980 - 1982

SUZUKI	450 GS450 E	1983 - 1983
SUZUKI	450 GS450 E	1983 - 1988
SUZUKI	450 GS450 L	1980 - 1982
SUZUKI	450 GS450 L	1983 - 1983
SUZUKI	450 GS450 L	1984 - 1988
SUZUKI	450 GS450 S	1980 - 1981
SUZUKI	450 GS450 S	1982 - 1983
SUZUKI	450 GS450 S	1988 - 1988
SUZUKI	450 GS450 T	1981 - 1982
SUZUKI	450 GS450 T	1983 - 1983
SUZUKI	450 GSX450 E /T	1980 - 1981
SUZUKI	500 RG500 Gamma	1986 - 1987
SUZUKI	750 GSX-R 750	1996 - 1997
SUZUKI	1100 GSX-R 1100	1995 - 1998
YAMAHA	250 RD250 (LC)	1973 - 1973
YAMAHA	250 RD250 (LC)	1974 - 1975
YAMAHA	250 RD250 (LC)	1976 - 1976
YAMAHA	250 RD250 (LC)	1977 - 1977
YAMAHA	250 RD250 (LC)	1978 - 1979
YAMAHA	350 RD350 luftgekühlt	1973 - 1976
YAMAHA	500 SR500	1978 - 1983
YAMAHA	500 SR500	1984 - 1987
YAMAHA	500 SR500	1988 - 1990
YAMAHA	500 SR500 (Trommelbremse/drum/	1988 - 1999